

DMG1.1**Modulating Actuators AC/DC 24 V****Application**

The **JOVENTA STANDARD** electric damper actuator series is designed to operate air dampers in ventilation and air conditioning systems. The compact design and universal adapter fitted with limitation of rotation angle make this JOVENTA actuator highly versatile.

Features

- DC 0...10 V or 0...20 mA control signal
- Working area adjustable
- Load-independent running time
- Up to 5 actuators in parallel operation possible
- Plug-in terminal block connection
- Simple direct-mount with universal adapter on 10...20 mm Ø round-axis or 10...16 mm square shaft
- 48 mm minimum damper shaft length
- Selectable direction of rotation
- Limitation of rotation angle
- Manual release button
- 2 adjustable auxiliary switches
- Automatic shut-off at end position (overload switch)
- Actuators available with 1 m cable
- Customized versions available
- Devices meet CE requirements

Accessories

- ZK Damper linkage selection
- ZKG Ball joints

**Technical Specifications**

Actuator	DMG1.1(S)
Torque	32 Nm
Damper area*	6.0 m ²
Running Time OPEN	200 s
Running Time CLOSE	200 s
Supply Voltage	AC/DC 24 V
Frequency	50-60 Hz
Power Consumption	
- Running	2.5 W
- At end position	0.3 W
Dimensioning	4.5 VA / 3.6 A @ 2 ms
Working area Y	not adjustable
Control Signal Y1	DC 0... 10 V
Input resistance Y1	Ri 250 Ω
Control Signal Y2	0...20 mA
Input resistance Y2	Ri 388 Ω
Position signal U	DC 0...10 V
Load resistance	> 50 kΩ
Angle of rotation/Working range	90° (93°mech.)
Angle of rotation/Limitation	5°...85° in 5° < steps
Auxiliary Switches	3(1.5) A, AC 230 V
- S1 setting range	5°...85° < adjustable
- S2 setting range	
Cable	
- Motor	1.0 m halogen-free
- Switches	5-Wire 1-2-4-5-6 5-Wire 21-22-23-24-25
Life time	60,000 rotations
Noise level	45 dB (A)
Protection Class	II
Degree of Protection	IP 54
Mode of Action	Type 1
Ambient conditions	
- Operating temperature	-20...+50 °C / IEC 721-3-3
- Storage temperature	-30...+60°C / IEC 721-3-2
- Humidity	5...95% r.F. no condensed
Weight	1.1 Kg
Service	Maintenance-free
Standards	
- Mechanics	EN 60 529 / EN 60 730-2-14
- Electronics	EN 60 730-2-14
- EMC Emissions	EN 50 081-1:92 / IEC 61000-6-3:96
- EMC Immunity	EN 50 082-2:95 / IEC 61000-6-2:99


*Caution: Please note damper manufacturer's information concerning the open/close torque.

Ordering Codes


Codes	Descriptions
DMG1.1	AC/DC 24 V
DMG1.1S	AC/DC 24 V, with 2 auxiliary switches

DMG1.1
Modulating Actuators AC/DC 24 V


Wiring Diagram



Parallel Connections




Position transmitter



The DMGxx can also be controlled using the JOVENTA Positioner (PA/PF) with control signal of DC 0...10 V. For further information concerning the PA and PF positioner please refer to sheet 6.20.

Caution: A maximum of 5 actuators can be controlled in parallel operation.

Dimensions in mm




Setting the control Signal

Control signal Y1	DC 0...10 V
Input resistance	Ri 250 k Ω
Control signal Y2	0...20 mA
Input resistance	Ri 388 Ω
Position signal U	DC 0...10 V
Load resistance	> 50 k Ω

By switching microswitch **d1** to ON position, the control signal Y1 or Y2 will be adapted to the chosen angle of rotation.

By switching microswitch **c** the direction of rotation can be changed.



Setting Span and OFFSET

The potentiometers **O** and **S** help to match control signals Y1 and Y2 to any make of controller.

Example 1

Control signal Y1 working between DC 2...10 V

Setting:	Starting point	O = 2
	working range	S = 8

Example 2

Control signal Y2 working between 6...18 mA

Setting:	Starting point	O = 3
	Working range	S = 6

Start point O


	Scale O	0	1	2	3	4	5	6	7	8
	for Y1 (VDC)	0	1	2	3	4	5	6	7	8
	for Y2 (mA)	0	2	4	6	8	10	12	14	16

Working range S


	Scale S	2	3	4	5	6	7	8	9	10
	for Y1 (VDC)	2	3	4	5	6	7	8	9	10
	for Y2 (mA)	4	6	8	10	12	14	16	18	20

DMG1.1
Modulating Actuators AC/DC 24 V

Auxiliary Switches (S)



Override Control




The actuator DMGxx can be forced to override control when wired in accordance with the diagram.

- Switch position:
- 1 = Actuator runs at 10 V
 - 2 = Actuator runs at 0(2) V
 - 3 = Automatic control


Settings the auxiliary switches

Factory setting
Switch **a** at 10°
Switch **b** at 80°

The switching position can be manually changed to any required position by turning the ratchet




Limitation of Rotation Angle



The limitation or rotation angle can be set in 5° steps by moving the adapter.

Adapter release



The adapter can be removed simply by pressing the adapter clip on the underside of the actuator